

-Connecting and disconnecting methods-

Connecting



- Confirm the Female end and the Male end of the pipes. The Female end has a slide piece.
- Insert Male end fully against the stopper bead on socket.

Disconnecting



- Pull each end apart after inserting the Male end fully against the stopper bead on Female end while holding the slide piece cover firmly.

Caution:

If the slide piece is moved and the pipes are pulled out, the joint system will lock in its place. Try inserting the Male end fully back against the stopper bead before disconnecting. Rotating the pipe makes it easier to disconnect.